



# Electrolux

## Instruction Book

사용 설명서

Sách Hướng Dẫn

Buku Petunjuk

คู่มือการใช้งาน

Livre d'instructions


کتاب التعليمات

## 500 Bagless cleaner









EFC52513DB / EFC52513OG

EFC52512 / EFC52522

EFC52611 / EFC52614 / EFC52623



\*Actual product may differ from illustration.



\* Accessories may vary from model to model. | 액세서리는 모델마다 다를 수 있습니다. | Phụ kiện có thể khác nhau giữa các kiểu máy.  
 Aksesori mungkin berbeza dari model ke model. | อุปกรณ์เสริมอาจแตกต่างกันในแต่ละรุ่น | Les accessoires peuvent varier d'un modèle à l'autre. |  
 قد تختلف الملحقات بحسب النموذج



Carpet





Hard Floor







Power adjustment



Note: This instruction book should be read together with safety precaution booklet.

www.electrolux.com









Twist about 30 degree



P





P




↻


2M  Max 40°C




12 M 









24h+ 









Max




Max 40°C




24h+







24h+




Click!





[www.shop.electrolux.com](http://www.shop.electrolux.com)



**ESKW9**

900 923 828


**Performance Filter Kit**



**KIT09C**

900 923 349


**Home and Car Kit**



**ZE161**

900 923 558

**Extra Wide Nozzle**



**ZE165**

900 168 381

**Speedy Clean Nozzle**



**ZE060.1**

900 168 381

**Textile Turbo**

The availability of spare parts may vary from country to country. | 부품 구매 가능 여부는 나라에 따라 다를 수 있습니다. | Các linh kiện thêm có thể khác nhau tùy theo quốc gia. | Ketersediaan suku cadang dapat bervariasi dari satu negara ke negara lain. | อะไหล่ที่จำหน่ายอาจแตกต่างกันไปในแต่ละประเทศ

**Online user manual**



# ELECTROLUX OFFICE ADDRESS

## 中国

伊莱克斯 (中国) 电器有限公司  
中国, 上海, 虹口区公平路168号上海北外滩来福士广场  
办公楼 第30层  
售后服务: +86 9510 5801  
网站: www.electrolux.com.cn  
官方微信公众号: 伊莱克斯北欧品味家



## 대한민국

일렉트로룩스코리아(주)  
(03188) 서울특별시 중로구 청계천로 41,  
영풍빌딩 22F  
고객센터: +82 1566-1238  
이메일: homecare.krh@electrolux.com  
팩스: +82 2 6020-2272  
홈페이지: www.electrolux.co.kr

## SINGAPORE

Electrolux SEA Pte Ltd  
351 Braddell Road, #01-04, Singapore 579713  
Customer Care Hotline: +(65) 6727 3699  
Email: customer-care.sin@electrolux.com  
Website: www.electrolux.com.sg

## THAILAND

Electrolux Thailand Co., Ltd.  
Electrolux Building  
14th Floor 1910 New Petchburi Road  
Bangkapi, Huay Kwang  
Bangkok 10310  
Thailand  
Tel: +(66) 2 725 9100  
Fax: +(66) 2 725 9299  
Electrolux Customer Care: +(66) 2 725 9000  
Email: customercareshai@electrolux.com  
Line ID: @electroluxth-care  
Website: www.electrolux.co.th

## PHILIPPINES

Electrolux Philippines Inc.  
12th Floor, Cyber Sigma Building  
Lawton Ave, Mckinley West, Taguig, 1634 Metro Manila, Philippines  
Tel: +(63) 2 8737 4757  
Domestic Toll Free: 1 800 10 845-CARE (2273)  
Customer Care Services: +(63) 2 8845-CARE (2273)  
Email: wecare@electrolux.com  
Website: www.electrolux.com.ph

## INDIA

Electrolux India Private Limited  
1st Floor, Plus Offices, Landmark Cyber Park, Sector 67,  
Gurugram,  
122018 Haryana, India  
Contact Number: 1800 202 1800  
Website: www.electrolux.in

## AUSTRALIA

Electrolux Home Products Pty Ltd  
ABN 51 004 762 341  
163 O'Riordan Street, Mascot,  
NSW 2020, Australia  
Customer Care Centre: 13 13 49  
Website: electrolux.com.au

## SOUTH AFRICA

Electrolux South Africa (Pty) Ltd  
3 Aberdeen Road, Benoni Industrial Sites  
Benoni, 1501,  
Johannesburg  
South Africa  
Tel: +27 11 897 4600  
Website: www.electrolux.co.za

## 台灣

新加坡商伊萊克斯股份有限公司 台灣分公司  
105408 台北市松山區敦化南路一段3號4樓  
免付費客服專線: 0800-888-259  
電郵: service.tw@electrolux.com  
網站: www.electrolux.com.tw

## HONG KONG

大昌貿易行有限公司  
電器維修中心  
香港九龍灣啟祥道20號  
大昌行集團大廈4樓  
服務熱線: (+852) 3193 9888  
電子郵件: customercare@dch.com.hk  
網頁: www.electrolux.com.hk

## MALAYSIA

Electrolux Home Appliances Sdn Bhd (175660-T)  
Lot C6, No.28, Jalan 15/22,  
Taman Perindustrian Tiong Nam, Seksyen 15,  
40200 Shah Alam, Selangor Darul Ehsan,  
Malaysia  
Customer Care Hotline: 1300-88-1122  
Email: Malaysia.customercare@electrolux.com  
Website: www.electrolux.com.my

## VIETNAM

Electrolux Vietnam Ltd  
Floor 10, Sofic Tower  
10 Mai Chi Tho street  
Thu Thiem ward – Thu Duc City  
Ho Chi Minh City  
Vietnam  
Tel: +(84 28) 3910 5465  
Fax: +(84 28) 3910 5470  
Customer Care Services: 1800-58-8899  
Email: vncare@electrolux.com  
Website: www.electrolux.vn

## MIDDLE EAST

Electrolux Appliances Middle East  
DMCC 40th Floor, Mazaya Business Avenue BB1,  
Jumeirah Lake Towers, P.O. Box 336148  
Dubai, United Arab Emirates  
Tel: +(971) 4 5100 200  
Service: servicemea@electrolux.com  
Website: www.electroluxarabia.com

## INDONESIA

PT Electrolux Indonesia  
Electrolux Building  
Jl. Abdul Muis no. 34, Petojo Selatan,  
Gambir, Jakarta Pusat 10160, Indonesia  
Tel: +(62) 21 5081 7300  
Fax: +(62) 21 5081 7399  
Customer Care Services: +(62) 0804 111 9999  
Email: customercare@electrolux.co.id  
Website: www.electrolux.co.id

## NEW ZEALAND

Electrolux (NZ) Limited  
3-5 Niall Burgess Road, Mount Wellington,  
Auckland 1060, New Zealand  
Customer Care Centre: 0800 436 245  
Website: electrolux.co.nz

