











Electrolux

SILENTPERFORMER™ CYCLONIC



R Recommended nozzle | 推薦吸頭 | 推荐吸嘴 | Nosel yang disarankan | Muncung yang disyorkan | đầu hút được khuyến nghị | หัวดูดฝุ่นที่แนะนำ | 권장 노즐



*Applies to certain models only. Accessories may vary from model to model. | 僅適用於特定型號。配件可能因機型而有所不同。 | 仅适用于特定型号。配件可能因型号不同而有所差异。 | Berlaku hanya untuk model tertentu. Aksesori dapat bervariasi dari model ke model. | Berkenaan dengan model yang tertentu sahaja. Aksesori mungkin berbeza-beza daripada satu model kepada model lain. | Chỉ áp dụng cho một số kiểu máy. Phụ kiện có thể khác nhau theo từng model. | ใช้กับเครื่องใช้ไฟฟ้าบางรุ่นเท่านั้น. อุปกรณ์เสริมอาจแตกต่างกันไปตามรุ่น. | 특정 모델에만 적용. 부속품은 모델별로 다를 수 있습니다.

